IBM

"Selectric" Typewriter

Adjustment Parts Manual

S241-5939-2

IBM "Selectric" Typewriter (7XX)
IBM "Selectric" II Typewriter (8XX)
IBM "Selectric" III Typewriter (670X)
IBM 96 "Selectric" Typewriter (9XX)

The drawings and specifications contained herein shall not be reproduced in whole or in part without written permission.

IBM has prepared this maintenance manual for the use of IBM Customer Engineers in the installation, maintenance and repair of the specific machines indicated. IBM makes no representations that it is suitable for any other purpose.

Information contained in this manual is subject to change from time to time. Any such change will be reported in subsequent revisions or distributed through Customer Engineering Memorandums (CEMs) to all subscribers.

Requests for copies of IBM publications should be made to your IBM representative or to the IBM Branch Office servicing your locality.

Comments about the publications may be addressed to (IBM Corporation, 740 New Circle Road N.W., Information Development, Dept. A58, Lexington, Ky. 40511). IBM may use or distribute any of the information you supply in any way it believes appropriate without incurring any obligation whatever. You may, of course, continue to use the information you supply.

"It is possible that this material may contain reference to, or information about, IBM products (machines and programs), programming, or services that are not announced in your country. Such references or information must not be construed to mean that IBM intends to announce such IBM products, programming, or services in your country."

"IBM," "Executive," "IBM EXECUTARY," and "Selectric" are registered trademarks of the IBM Corporation.

©Copyright International Business Machines Corporation 1964, 1966, 1967, 1968, 1969, 1971, 1973, 1975, 1976, 1979, 1980

SAFETY PRECAUTIONS

All IBM Customer Engineers are expected to take every safety precaution possible and observe the following safety practices when servicing IBM equipment.

***Mechanical Safety**:*

1. *Safety glasses must be worn.*
2. *All safety devices, such as guards, shields, signs, ground wires, etc., must be restored after maintenance. When a guard or shield is removed to observe or make an adjustment, that shield must be replaced when work in the area is completed.*
3. *Watches, rings, necklaces, ID bracelets, etc., must be removed when servicing the machine.*
4. *Care must be used when working near moving parts. Keep hair away from moving parts. Avoid wearing loose clothing that might be caught in the machine. Shirt sleeves must be kept buttoned or rolled above the elbows. Ties must be tucked in the shirt or have a tie clasp approximately three inches from the end. Tie chains are not recommended.*

***Electrical Safety**:*

1. *The equipment referenced in this manual may use high voltages. Check voltage labels!*
2. *Safety glasses must be worn when checking energized circuits.*
3. *If a circuit is disconnected for servicing or parts replacement, it must be reconnected and tested before allowing the use of the machine.*
4. *Power should be removed from the machine for servicing whenever possible. Remember, when checking voltages, avoid contacting ground potential, such as metal floor strips, machine frame, etc.*
5. *Meter continuity checks should be used instead of voltage checks whenever possible.*
6. *Do not apply power to any part, component, or subassembly when it is not physically mounted in the machine.*

***General Safety**:*

1. *Each Customer Engineer is responsible to be certain no action on his/her part makes the product unsafe or exposes customer personnel to hazards.*
2. *Store the removed machine covers in a safe, out of the way place where no one can trip over them.*
3. *If you must leave the machine in a down condition, always install the covers and disconnect the power before leaving the customer's office.*
4. *Always place CE tool kit away from walk areas where no one can trip over it.*
5. *Maintain safe conditions in the area of the machine while performing and after completing maintenance.*
6. *Before starting the equipment, make sure fellow CEs and customer personnel are not in a hazardous position.*
7. *All the machine covers must be in place before the machine is returned to the customer.*

***Note**: Refer to the Safety CEMs relating to this product(s) for further safety precautions.*

INTRODUCTION

This manual is written for both U.S. and World Trade usage. It contains an adjustment section, a parts manual section, and a diagnostics section for the following products:

Product Name	Identification Code	Product Code
IBM "Selectric" Typewriter	7XX	21
IBM "Selectric" II Typewriter And IBM Correcting "Selectric" II Typewriter	8XX	26
IBM "Selectric" III Typewriter And IBM Correcting "Selectric" III Typewriter	670X	27
IBM 96-Character "Selectric" Typewriter	9XX	

World Trade Note: The IBM 96-Character "Selectric" Typewriter applies only to some World Trade countries.

ADJUSTMENT SECTION

Purpose

This section provides a reference for the most commonly used adjustments. Refer to other product service publications if additional information is needed.

Adjustment Identification

The headline of each page shows the product name identification code, product code, and the name of the mechanism covered on that page. Each adjustment is indicated by a black frame number in the top left corner, followed by the adjustment name and mechanism code/reference number. If one frame covers adjustments for more than one product or product level, they are indicated by the identification code and/or the level number. The machine mode, the view of the drawing, and safety precautions are also noted when required.

Adjustment Sequence

The frame numbers indicate the sequence of adjustments. One adjustment could affect a following adjustment. Therefore, check all the following adjustments in that mechanism. A solid red bar indicates the end of the mechanism.

Red numbers on the bottom left corner of the frame indicate adjustments out of sequence that could be affected and should be checked.

Adjustment Procedure

The part to be adjusted is colored red, and a red arrow shows the direction of movement. Tolerances and/or additional information on how to perform the adjustment are shown when required.

Always use the adjustment tolerance shown in the publication with the latest date.

Call Reporting (U.S. Only)

Use the mechanism codes/reference numbers shown after the frame number and frame name for call reporting. The reference number is not always the number of the part that is colored red.

PARTS MANUAL SECTION

Introduction

This section contains parts drawings of mechanisms, reference numbers and other special information. It must be used with a separate part number/price list manual which contains reference numbers, part numbers, part descriptions and prices.

Mechanism Identification

The headline of each page shows the product name, identification code and product code covered on that page. The headline of each frame (two frames per page) shows the mechanism name and the mechanism code covered in that frame. Some frames will show a model identification code after the mechanism name. Some mechanisms require more than one frame. However, each mechanism consists of a group of parts that work together to perform a function.

Part Identification

Red numbers indicate the reference number of a part, a bill of material (B/M) or an assembly.

Red blocks within a frame indicate either one, or a combination of more than one, of the following:

- Differences between the models (7XX, 8XX, 670X, or 9XX)
- Different modes within the same model [for example: rotary backspace (RB/S) and non-rotary backspace (NRB/S)]
- Different machine sizes (7X1, 7X3, or 7X5 "Selectric" Typewriter)
- Different levels within the same model, mode, or size (level 1, level 2, etc.). (8X3 and 8X5 apply to the "Selectric" Typewriter.) (XX3 and XX5 apply to the "Selectric" Typewriter and "Selectric" II Typewriter.)
- Field replacement parts
- Bill of material (B/M) or assemblies (shown with a description – parts shown in the drawing)
- World Trade applications or differences

If different levels exist, which can be used for all models, modes or sizes, only the newest level is shown in the drawing. However, the part number/price list manual will show all level parts.

(Continued On Page 4)



Covers & Mountings	04/05
Sound Reduction	30
Special Features ...	39 Thru 51
Packing Parts & Inst.	65

IBM "SELECTRIC" TYPEWRITER
CONTENTS
(Alphabetical)

PARTS			ADJUSTMENTS	
Mech Code	Page	Mechanism	Frame	Page
		INTRODUCTION		1
		Backspace		
24	89	Express Backspace	184	28
07	68	Half Backspace	179	27
01	61	Non-Rotary Backspace (NRB/S)	163	26
24	89	Rotary Backspace (RB/S)	167	26
	62	Cardholder Chart		
02	61	Carrier		
03	64	Carrier Return	151	23
23	88	Character Selection	55	11
		Character Selection (Rotate Tool)	67	13
		Character Selection (Typehead)	75	14
26	91	Correcting	311	44
04	65	Covers & Mountings (7XX)	359	50
05	66	Covers & Mountings (8XX, 9XX)	359	50
05	67	Covers (670X)	359	50
06	68	Escapement (NRB/S)	85	15
07	68	Escapement (RB/S)	85	15
		Fine Alignment	43	9
08	69	Frames		
20	82	Indexing	246	37
20	83	Indexing (Double)	369	52
20	83	Indexing (W.T.)	246	37
21	84	Keyboard	12	6
21	85	Keyboard (Dual Impression)	11	6
09	71	Linelock & Bell	340	48
09	70	Margins (NRB/S)	340	48
10	71	Margins (RB/S)	340	48
11	75	Motor & Drive (Canadian)	1	5
11	73	Motor & Drive (Netherlands)	1	5
11	72	Motor & Drive (U.S.)	1	5
25	90	Operational Control	118	20
25	90	Operational Shaft Assembly		
22	86	Paper Feed ("A-Frame")	234	35
22	86	Paper Feed (Tie-Rod)	234	35
12	76	Platen		
		Print	213	32
13	76	Ribbon, Fabric	278	41
14	77	Ribbon, Film	262	38
15	78	Ribbon, Selective	291	42
02	63	Rocker (Gear Type Tilt)		
02	63	Rocker (Gearless Type Tilt)		
23	88	Selection		
16	78	Shift	32	8
17	79	Spacebar	126	22
18	80	Tab (NRB/S)	190	29
19	81	Tab (RB/S)	190	29
02	63	Type Elements		
		FEATURES		
39	93	Cardholding Platen		
40	93	Dead Key (U.S.)	363	51
40	94	Dead Key (W.T.) Thailand		
40	93	Dead Key Disconnect	366	51
13	76	External Ribbon Control	376	52
45	95	Handicapped Attachments		
21	84	Manual Velocity Control	378	53
49	97	Overhead Pin Feed Platen (W.T.)		
49	96	Pin Feed Platen	381	53
41	94	Shift Sensing (Dual Impression)	386	54
30	92	Sound Reduction		
51	97	Stroke Counter		
		GENERAL INFORMATION		
		Broken Tapes Check		55
		Cause Of Failure Codes		Inside Rear Cover
		Common Abbreviations		4
		Correcting Diagnostics		57
		Functional Check		55
		Identification Codes		Inside Rear Cover
		Lubrication Guide		54
		Ribbon Applications		56
		Safety Precautions		Inside Front Cover
		Service Call Procedure		54
		Type Element Arrangement		56
		Voltage Checks "Selectric" III Dual-Pitch Typewriter		58
		Wiring Diagrams		60
		BOLT DOWN PARTS AND INSTRUCTIONS		
	93	Bolt Down Instructions		
04	60	Bolt Down Parts (7XX)		
05	61	Bolt Down Parts (8XX, 9XX, 670X)		
		PACKING PARTS AND INSTRUCTIONS		
65	100	Packing (U.S.)		
65	98	Packing (W.T.)		
		CHARTS		
		Cardholder Chart		62
04		*Painted Cover Parts (7XX)		
05		*Painted Covers Parts (8XX, 9XX)		
12		*Platen Indexing		

*These charts are printed in the Part Number/Price List (P/N 241-5103).

(Introduction Continued From Page 1)

Some parts are shown for assembly purposes only and do not show a reference number. Replace these parts by ordering either the assembly or a later level part.

Parts Ordering
Locate the mechanism in which the part functions by using the contents page. Note the mechanism code, find the part in the drawing, and note the reference number. Use this mechanism code/reference number to locate the part number and price in the part number/price list manual.

World Trade should use the country's procedures to find the prices.

Features and devices (MESs) or specification changes (SERs) desired by the customer must be ordered through CE management and Branch Office sales.

Replacement parts for features, devices and SERs not shown in the parts manual must also be ordered through CE management and Branch Office sales.

COMMON ABBREVIATIONS

The following list is provided as a reference for some of the common abbreviations used in this manual. It should be noted that some of these are new since the last revision.

APM	**Adjustment Parts Manual**
ASM	**Assembly**
AVC	**Automatic Velocity Control**
B/M	**Bill Of Material**
CC	**Cycle Clutch**
CR	**Carriage Return**
CSI	**Combined Service Information**
DI	**Dual Impression**
DP	**Dual Pitch**
ECC OT	**Eccentric Index Overthrow Stop**
FI	**Field Installable**
FTB	**Floating Torque Bar**
g	**Grams**
mm	**Millimeters**
NRB/S	**Non-Rotary Backspace**
PN/PL	**Part Number/Price List**
Pre-DI	**Pre-Dual Impression**
Pre-FTB	**Pre-Floating Torque Bar**
RB/S	**Rotary Backspace**
SB	**Spacebar**
SER	**Special Engineering Request**
SHP	**Shop Manual 241-6670**
SP	**Single Pitch**
TII	**Technical Information Index**
TYP	**Type Catalog 241-5687**
UBS	**Upper Ball Socket**
W.T.	**World Trade**

1 Cycle Shaft End Play (23-421)



2 Gear Train Backlash (23-461)



3 Cycle Clutch Latch Bracket (21-532)



4 Cycle Clutch Spring (23-404)



5 Cycle Clutch Sleeve End Play (23-409)



6 Cycle Clutch Drive (23-404)



7 Cycle Clutch Overthrow (23-412)



8 Drive Belt (11-68)



Motor And Drive, Keyboard

9 Motor Fan (11-400)



(Top View) *(U.S. Only)*

10 Motor Pulley (11-48)



(Rear View)

11 Motor Clutch Pawl Stops (11-43)



(Metal Hub Only)

12 Keyboard Position (21-100)



13 Filter Shaft (21-114)



40, 108, 145, 232

14 Filter Shaft End Play (21-121)



15 Rear Bearing Support (21-06)



21, 22, 23

16 Rear Interposer Guide Comb (21-29)



17 Bail Mounting Plate (21-303)



59 *(Bottom View)* *(Front View)*

18 Keeper Bracket (21-204)



42

19 Cycle Bail Damper Spring (21-240)



20 Cycle Clutch Latch Restoring (21-206)



(Level 1) *(Level 2)* *(Level 2 – Top View)*

21 Interposer Latch Springs (21-4)



26, 27

22 Cycle Clutch Keeper (21-205)



23 Cycle Bail Upstop (21-208)



24 Front Keylever Guide Comb (21-132)



Interposer Must Not Bottom In Rear Guide Comb

37, 127, 128, 186, 196

25 Compensator Tube (21-28)



(Level 1) *(Level 2)* *(Level 3)* *(Level 4)* *(Level 5)*

16

26 Typamatic Keylever (21-109)



27 Repeat Keylever (21-106)



Keylever At Rest

.015"-.020"
(0.38-0.51 mm)

Keylever Fully Depressed

.005"-.015"
(0.13-0.38 mm)

Interposer Must Not Bottom In Rear Guide Comb

Just Touching

Must Not Touch

Must Latch Interposer To Front During Repeat

(Level 2)

(Level 1)

28 Switch Link (21-709)



Adjust To Match Slope Of Keyboard

29 Lockout Bail Link (21-546)



Equal Over Center Travel Of Bellcrank

30 Lockout Bail Bellcrank (21-553)



Switch In OFF Position

Bail Under CC Latch Lug

NOTE: Keyboard Lock Interposer Clears Compensator Tube With Switch In ON Position

31 Keyboard Lock Bellcrank Link (21-305)



Bottomed Without Choking Off Bail

32 Shift Cam Backup Roller (16-46)



.001"-.004"
(0.03-0.10 mm)

77 *(Level 1 – Rear View)*

33 Shift Cam Bearing (16-112)



Without Washer

.000"-.003"
(0.00-0.07 mm)

With Washer

.000"-.001"
(0.00-0.03 mm)

120, 121 *(Level 2)*

34 Shift Spring Clutch Retaining Plate (16-55)



Plastic And Steel Sintered Cams Upper Case – 1-1/2 To 2 Teeth Rotation Of Ratchet When Released

Early Level Metal Cam Lower Case – 1 Tooth Rotation Of Ratchet When Released

35 Shift Overthrow Stop (16-203)



.010"-.030"
(0.25-0.76 mm)

36 Shift Bracket (16-208)



.045"-.065"
(1.14-1.65 mm)

Clears Tension Pulley In Operated Position

37 Shift Release (16-19)



38 Shift Lock (16-37)



39 Shift Interlock (16-73)



40 Shift Interlock Cam (16-14)



41 Character Interrupter (21-285)



42 Character Interrupter Bracket (21-287)



43 Carrier Shoe (02-107) (02-119) (02-112) (02-96)



44 Print Sleeve End Play (02-152) (26-56)



(Level 1 – Pre-Dual Impression) *(Level 2 – Dual Impression)* *(Level 3 – Correcting Only)*

45 Rocker End Play (02-530)



(Top View)

46 Tilt Tube End Play (02-305)



(Front View) *(Right Side View)*

47 Rotate Shaft End Play (02-415)



(Pre-Dual Impression) *(Dual Impression)*

48 Upper Ball Socket (02-400)



49 Tilt Ring Spacer (02-402)



(Level 1) *(Level 2)* *(Level 3)*

50 Rotate Detent (02-406)



(Level 1) *(Level 2)*

51 Tilt Detent (02-311)



52 Tilt Ring Pivot Pins (02-300)



Gearless Tilt Mechanism *Gear Tilt Mechanism*

53 Detent Cam Follower Bracket (02-501)



54 Skirt Clearance (02-505)



55 Print Shaft Timing (Preliminary) (02-30)



56 Latch Bail Shaft (23-115)



57 Differential Guides (23-207) (23-34)



58 Positive Latch Bail Guide (23-107)



59 Interposer Stop Lugs (21-310) (21-325)



60 Selector Latch Links (21-316)



(Levels 1 & 2)

(Level 3)

61 Negative 5 Or 6 Latch Link (21-317)



(Levels 1 & 2)

(Level 3)

62 (Latch Stop Pads (23-486)



63 Negative Bail Stop Screw (Preliminary) (23-216)



(Level 1)

(Level 3)

(Level 2)

64 Tilt Arm Motion (23-28)



65 Tilt Homing (23-007)



66 Rotate Spring Tension (02-424)



67 Compensator Arm (23-363)



Compensator Arm Must Be Disabled. See Service Manual

68 Rotate Arm Vertical (Preliminary) (23-367)



Scribe Line Centered On Screw

(Compensator Arm)

(U.S. Only)

(Solid And Two Piece Arm)

69 Preliminary Homing (02-420)



Rotate Tool

Rotate Detent Just Touches

No Binds No Clearance

Adjustment	Shift	Character	Tool Slot	Adjust
Preliminary Homing	UC	I Tilt 2 +3 Rotate	U	Rotate Pulley W.T. L-2/UBS

70 Zero Rotate (23-228)



No Binds No Clearance

Leave Turnbuckle Loose

Adjustment	Shift	Character	Tool Slot	Adjust
Zero Rotate	UC	1/4 Tilt 2 Zero Rotate	U	Turnbuckle W.T. L-2/UBS

71 Positive 5 Motion (23-369)



(Compensator Arm) (Solid Arm) (Two Piece Arm)



No Clearance No Binds

Adjustment	Shift	Character	Tool Slot	Adjust
+5 Motion	UC	W Tilt 2 +5 Rotate	+5	Rotate Arm

72 Negative 5 Motion (23-369)



No Clearance No Binds



Adjustment	Shift	Character	Tool Slot	Adjust
-5 Motion	UC	M Tilt 2 -5 Rotate	-5	Turnbuckle W.T. L-2/UBS

73 Balance (Final) (23-216)



No Clearance No Binds



Adjustment	Shift	Character	Tool Slot	Adjust
Balance	UC	1/4 Tilt 2 Zero Rotate	U	-5 Stop Screw

74 Shift Motion (16-101) (16-41)



(Stamped Arm) (Die Cast Arm)


No Clearance
No Binds

Adjustment	Shift	Character	Tool Slot	Adjust
Shift Motion	LC	1/2 Tilt 2 Zero Rotate	L	Shift Stop Screw

If character selection adjustments with rotate tool are complete, continue with frame 83.

75 Compensator Arm (23-363)

Compensator Arm Must Be Disabled See Service Manual



76 Rotate Arm Vertical (Preliminary) (23-367)



(Compensator Arm) (U.S. Only) (Solid and Two-Piece Arm)

77 Typehead Homing (Preliminary) (02-420) (02-441)



Upper Case	
Tilt 2 Zero Rotate	"Degree" – 7XX 8XX "R" – 670X


7XX 8XX


670X
9XX W.T.


8XX W.T.

78 Negative 6 Upstop (23-241)



(Right Side View)


(Rear View)

79 Rotate Arm Motion (23-369)


(Compensator Arm) (Solid And Two Piece Arm)

Upper Case	
"Degree" = "W"	7XX 8XX
"R" = "V"	670X
Tilt 2 Zero Rotate = Tilt 2 +5 Rotate	7XX 8XX 670X 9XX

80 Balance (Final) (23-216)



7XX 8XX	670X 9XX W.T.
"T" = "M"	"R" = "degree"
Tilt 1 Zero Rotate = Tilt 2 -5 Rotate	Tilt 2 Zero Rotate = Tilt 2 -6 Rotate



(Adjustable Balance Arm)

81 Typehead Homing (Final) (02-420) (02-441)



7XX 8XX

670X
9XX W.T.

8XX W.T.

Upper Case		
Tilt 2 Zero Rotate	"Degree"	7XX 8XX
	"N"	670X

82 Shift Motion (16-101) (16-41)



(Stamped Shift Arm) (Die Cast Shift Arm)

83 Fine Timing (02-30)





(Pre-Dual Impression) (Dual Impression)

Hand Cycle Upper Case M	Tilt 2 -5 Rotate	7XX 8XX
Hand Cycle Upper Case Degree	Tilt 2 -6 Rotate	670X 9XX W.T.

84 Rotate Pulley Guard (23-351)

.005"
(0.13 mm)
Clearance When
In Negative 5/6 Position



85 Escapement Rack Or Rail (07-11)

Hooverometer On Number One Scribe Line

Just Spans The Distance



(NRB/S)

(RB/S)

165

Check At Left, Center, And Right

86 Escapement Rack Guide (07-20)



89

(Dual Pitch Only) (Left Side View)

87 Escapement Rack Teeth Vertical (07-23)



(Rear View)

(Dual Pitch Only)

88 Escapement Rack Gear Lower Stop (07-20)



(Dual Pitch Only)

89 Switch Pitch Sector Gear (07-31)



(Left Side View) *(Top View)* *(Top View)*

172 *(Dual Pitch Only)* *7XX 8XX 9XX* *670X*

90 Escapement Pawl Guide Lug (07-4)



(RB/S)

91 Carrier Support (02-8)



670X

331 *XX3 XX5*

92 Carrier Shoe (07-4)



43, 91, 190, 207, 223, 331, 334 *(RB/S Only)*

93 Carrier Buffer (02-130)



94 Escapement Bracket (06-23)



Tab Adjustments *(NRB/S – Level 1)*



(NRB/S – Level 2)

(07-1)



(RB/S – Level 3)

95 Torque Bar (Preliminary) (06-029)



96 Escapement Torque Bar (06-33)



97 Pawl Mounting Stud (Preliminary) (06-26)



98 Torque Bar Upstop (Preliminary) (06-55)



99 Escapement Pawl Tail Clearance (23-50)



100 Center Torque Bar Backup Screw Final (06-59)



101 Left Torque Bar Backup Screw (Final) (06-13) (07-13)



102 Torque Bar Upstop (Final) (06-55)



103 Pawl Mounting Stud (Final) (06-26)



(Bottom View) (Level 1)

104 Tab Torque Bar Parallel (23-50)

Equal On Left
And Right End
At Closest Point



CR Latch Keeper Removed

105 Torque Bar Backstop (06-39)



(Level 1)

(Level 2)

106 Knock-Off Pivot Pin Eccentric (06-19)



(Level 1)

107 Escapement Cam (06-7)

Check On Both
Sides Of Cam



Low Point Machine At Rest

Escapement Should Occur Just After Print

W.T. Escapement
.042"-.060"
(1.00-1.50 mm)
After Print
Impression Control
At 5

108 Trip Link (06-10)



Check On Both
Sides Of Cam

Ensure Trigger Upstop And
Spacebar Motion Adjustment Are
Not Controlling This Adjustment

317

109 Trigger Knockoff (06-51)



(Level 1)

(06-19)



(Level 2)

(06-14)





(Level 3)

110 Trigger Upstop (Final) (06-36)



.001"-.005" (0.03-0.13 mm)

Centered

111 Spacebar Link (17-306) (07-40)



.001"-.012" (0.03-0.30 mm)

(RB/S)



.007"-.010" (0.18-0.25 mm)

(NRB/S)

112 Mainspring Hub (19-13)



Loosen Before Making Adjustment

.001"-.004" (0.03-0.10 mm)

122, 124

(Level 1)

(All Steel Transport)

113 Escapement Shaft Collar (03-363) (24-8) (24-6)



Minimum End Play No Binds

(NRB/S)

(All Nylon Transport)

122, 124



Minimum End Play No Binds

(Level 1 — RB/S)

(All Steel Transport)



Minimum End Play No Binds

(Level 2 — RB/S)

(Dual Transport)

114 Mainspring (18-95) (19-12)

This Spring Requires 5 Turns At The RH Margin



Long Ears

Short Ears

1/2-3/4 Lbs. (226.8-340.2 g) Tension As Carrier Escapes Through Extreme RH Margin

This Spring Requires 7 Turns At The RH Margin

115 Idler Pulley Eccentric (18-124) (19-16)



Pin Horizontal And Above Center Angled To Left Slightly

116 Cord Tension (03-363) (24-6)



Aligns With Scribe Line On Mounting Bracket

113

(NRB/S And Level 2 RB/S)

117 Cable Tension (19-23)



.040"-.050" (1.02-1.27 mm)

(Level 1)

(All Steel Transport)

118 Operational Shaft Support Bracket, Front To Rear (25-350)



119 Operational Shaft Support (25-56)



Just Touches With No Shaft Flex

120 Operational Shaft Position (25-24)



155, 184

121 Operational Shaft End Play (25-23)



122 CR Pinion Backlash (18-103)



Remove Play In Escapement Shaft To Rear

123 CR Pinion End Play (25-3)

Check With Power On



124 Tab Pinion Backlash (25-20)

Check With Power On

Remove Play In Escapement Shaft To Rear



125 Index Keylever Pawl Clearance (25-224)



126 Keylever Pawl Overlap (25-302) (25-238)



127 Spacebar Keylever Pawl Clearance (17-110) (17-150)



143, 144

(Level 1)

(Level 2)

128 CR And BS Keylever Pawl Clearance (03-101)



129 Check Ring (25-29)



130 Operational Cam Position (25-101)



(Top View)

131 Release Arm Overlap (25-205)

Maximum Overlap Without Touching Cam



(Bottom View)

132 Clutch Release Arm Overlap (25-205)

NOTE: Interposer Latched
Operational Cam Released Manually



(Right Side View)

133 Clutch Release Arm (25-205)



134 Interposer Restoring Bail (25-216)

Cam On High Point



(Level 1)

(Level 2)

135 Interposer Adjusting Screw (25-222)



Adjust	Adjustment
1. B/S And CR	.005"-.015" (0.13-0.38 mm)
2. SB (RB/S Machines)	To Match B/S And CR
3. Index	To Match All Others

136 Latch Height (17-300)



137 Latch Lever Screw (07-40)



138 Spacebar Link (17-306)



139 Spacebar Guide (17-129)



140 Spacebar Return (17-124) (17-146)



141 Spacebar Operating Arm (17-152)



142 Spacebar Operating Cam (17-132)



143 Repeat Stop (17-106) (17-148)



144 Spacebar Final Stop (17-119) (21-143)



145 Interlock Cam (17-353)



(Level 1)

NOTE: 96-Character Machine, Use Frame 107.

(Level 2)

146 Spacebar Lockout (17-353)



(Level 1)

147 Interposer Guide (25-238)



(Level 1)

148 Spacebar Interlock Bracket (25-226)



(Level 2)

149 Interlock Stop (25-232)



(Level 2)

150 Space-To-Print Interlock (17-404)



151 CR Latch Actuating Arm (03-203)



(Level 4 Only)

152 Pawl Clearance (03-420) (03-612) (03-203)



(Level 1) *(Levels 2 & 3)* *(Level 4)*

153 Latch Height (03-400)



154 Clutch Latch Overthrow (03-580)



155 Shoe Overlap (03-500)



156 Carrier Return Shoe Clearance (03-502)



157 Overbank (09-6)



Dual Pitch Machines Must Be Checked In 12P

Adjustment Must Be Checked While Holding Carrier Stop Latch To Right

RB/S Machines Hold Rail To Right Remove Play In Rack To Left

(Level 1)

(Level 2)

158 Overbank Motion (09-21)



(Level 1)

159 Clutch Unlatching (03-557)

(03-202)



Margin Rack Held To Left

RB/S – Clevis In Outside Hole

(Levels 1, 2, & 3)

(Level 4)

160 Torque Bar Latch (03-207)



(Level 4 Only)

161 Torque Limiter (25-5)



1 To 1-1/2 Lbs. (454-680.8 g) Pull

Adjust For Positive Carrier Return Near Left Margin

(Level 1)

(Level 2)

162 CR Printer Interlock (03-625)



Adjust For A Clearance At Rest And Positive Character Interruption When CR Is Latched

(Level 1)

(Level 2)

163 Backspace Latch Height (NRB/S) (01-309)



164 Tab Lever Stop (NRB/S) (01-314)



(Level 1)

(07-4)



(Level 2)

165 Backspace Rack (NRB/S) (01-307)



(Levels 1 & 2) (Level 3)

166 Backspace Rack Motion (NRB/S) (01-329)



165 (Level 1) (Level 2) (Level 3)

167 Mainspring Hub (RB/S) (19-13)



122, 124 (Level 1) (All Steel Transport)

168 Escapement Shaft Collar (RB/S) (24-8)



122, 124

(Level 1 – All Steel Transport) (Level 2 – Dual Transport)

169 Cable Tension (RB/S) (19-23)



(Level 1 – All Steel Transport)

170 Rotary Backspace (25-210) Interposer Spring



171 Pitch Cam Cable Cover (24-37)



(Dual Pitch Only)

172 Pitch Cam (24-37)



(Dual Pitch Only)

173 Backspace Motion (24-26)

NOTE: Dual Pitch Machines Check In 10 Pitch.



174 Backspace Latch Height (24-15)



(Level 1 Only)

175 Index Interlock Link (24-16)



176 Index Interlock Shaft (24-20)

(24-18)



177 Index Interlock Paddle (24-20)



178 Index Transfer Bellcrank Stop Lug (24-9)



179 Lower Half Backspace Link (07-7)

Characters Typed Between Characters



(Rear View) (Level 1)

180 Switch Pitch Gear (07-23)



(Levels 2 & 3)

181 Half Backspace Collar (07-105)



(Level 2)



(Level 3)

182 Half Backspace Rest Position (07-37)



(Level 1 — Pre- "A-Frame" Paper Feed)

(Level 1 — "A-Frame" Paper Feed)

183 Half Backspace Lever (07-32)



(Level 1)



(Levels 2 & 3)

184 Shoe Overlap (24-105)



185 Keylever Pawl Guide (25-238)



186 Shoe Clearance (24-111)



7XX 8XX 9XX



670X

187 Keylever Pawl (24-102)



(NRB/S)

188 Keylever Pawl (24-205)



670X

189 Express Backspace Latch (24-102)



(NRB/S)

190 Tab Rack Radially (18-35) (19-31)



Check 95 First.

(NRB/S Pre-Snap In Tab)



(NRB/S Snap In Tab And RB/S)



191 Tab Lever Stop (18-153)



Check 94 First.

(NRB/S)

(19-69)



(RB/S)

192 Tab Lever Pawl (18-152)



(NRB/S)

(19-68)



(RB/S)

193 Tab Rack Parallel



(Right Side View)

(18-30)



(NRB/S)

(19-29)



(RB/S)

194 Tab Latch Bite (19-9)



(RB/S)

195 Pawl Clearance (18-81)



(NRB/S)

(19-9)



(RB/S)

196 Tab Keylever Link (18-58)



(NRB/S And Level 1 RB/S)

(19-78)



(Level 2 – RB/S)

197 Tab Torque Bar Link (18-19)



(NRB/S)

198 Tab Torque Bar Link (19-47)



(Level 1) (RB/S) (Level 2) (Right Side View)

199 Tab Torque Bar Backup Lug (07-001)



(RB/S)

200 Tab Trigger (19-71)



201 Overthrow Stop (18-91)



202 Tab Lever Overthrow (19-41)



203 Tab Rack Left To Right (18-87)



204 Tab Interlock (18-81) (19-9)



205 Carrier Return Tab Interlock (03-575)



206 Tab Rack Vertical (18-30) (19-29)



193, 203

207 Tab Set And Clear Bracket (19-2)



208 Tab Set (18-16) (19-55)



209 Tab Clear Bracket (18-132)



210 Tab Clear (18-16)



211 Tab Set And Clear Link (19-54) (18-20)



212 Tab Pinion Backlash (25-20)



213 Copy Control Lever (22-254)



214 Platen Adjusting Plates (22-252)



215 Carrier Shoe (02-119)



216 Carrier Support (02-8)



217 Anvil (02-008)

Should Not Print { Period Or Point — Copy Lever -5

Light Print { Period Or Point — Copy Lever -4



218 Buffers (02-101)



219 Platen Latches (22-293)



220 Platen Front To Rear (22-253)


Touching With Copy Control In Position "A"
(NRB/S)
Gauge Held Up
Touching With Multiple Copy Control In Position "A"
Gauge Held Down
(RB/S)

221 Platen Height (22-291)



217
Check Paper Feed And Index

222 Print Cam Follower Stop Screw (02-205)



223 Powered Flight And Free Flight (02-160)



224 Print Cam Follower (02-165)



225 Cam Follower Restoring (02-165)



226 Yoke (02-520)



227 Velocity Control Cable Clamp (02-216)



228 Carrier Cable Deflector (19-74)



229 Center Cable Clamp (02-216)



230 Velocity Control Keyboard Cable Clamp (02-216)



231 Low Velocity Latch Link (21-411)



232 Low Velocity Cam (21-426)


Low Velocity Character On High Point Cam
Second Scribe Mark
.008"-.012" (0.20-0.30 mm)

233 Low Velocity Cam Follower Stop (21-415)



234 Paper Feed Support (22-208)



(Tie Rod Only)

235 Platen Latches (22-293)



236 Feed Roll Tension (22-286)



(Tie Rod)

("A-Frame")

237 Feed Roll End Play (22-96)



(Tie Rod Only)

238 Feed Rolls (22-286)



(Level 1 – Tie Rod)

(Level 2 – Tie Rod)

("A-Frame")

239 Paper Release (22-93)



(Tie Rod) *("A-Frame")*

240 Deflector (22-134)



(Tie Rod) *("A-Frame")*

241 Paper Bail (22-1)



If Necessary Form The Bail Shaft To Obtain Equal Bail Roll Contact With Platen

242 Cardholder (22-216)



243 Removable Print Shield (22-226)



244 Paper Table Arm (04-90) (05-56)



245 Paper Table Mounting Bracket (04-92) (05-47)



7XX 8XX 9XX

(05-141)



(670X Only)

(Left Side View)

(30-141, 166)



(670X Only)

(Left Side View)

(Sound Reduction Only)

246 Switch Bracket (24-9)



Adjust So Lower Index Link Does Not Bind In Slot

Check 119

(RB/S Only)

247 Multiplying Lever Stop (20-412)



3/8" 27, 32, 54T (9.53 mm)
13/32" 24, 45, 48T (10.32 mm)
11/32" 36T (8.73 mm)

Clevis In Rear Hole For 36T

248 Index Transfer Bellcrank Stop Lug (24-9)



Form

Minimum Clearance No Binds

(RB/S Only)

249 Ratchet Alignment (12-20)



Shims

Pawl Even With Ratchet

250 Index Selector Cam (20-318)

Cam At Rest
Double Space Position
Index Pawl Manually Activated



.010"-.040" (0.25-1.02 mm)

Pawl Centered On Camming Surfaces In Single And Double Space Position

Just Bottomed

(Level 2)

251 Index Selector Cam 54T (20-322)

Cam At Rest
1-1/2 Line Space Position
Index Pawl Manually Activated



Just Bottomed

.005"-.030" (0.13-0.76 mm)

252 Index Link (20-403)



Double Space Adjust For 2 Teeth Motion Of Platen Plus 1 Turn Of Clevis

Move Overthrow Stop To Front Of Machine

(Level 2)



Move Overthrow Stop To Front Of Machine

(Level 3)

253 Overthrow Stop (20-452)



Minimum Clearance No Binds

(Level 2)



Index Cam On High Point

Minimum Clearance No Binds

(Level 3)

254 Index Link And Stud (20-401)



(Level 1 Only)

255 Upper Index Pawl Stop (20-437)



(Level 1 Only)

256 Multiplying Control Lever (20-314)



(Level 1)

257 Platen Overthrow Stop (20-452)



(Level 1)

258 Index Selector Lever (20-301)



(Level 1)

259 Line Position Reset Lever (12-32)



260 Left Platen Knob (12-55)



261 Right Platen Knob (12-55)



262 Ribbon Lift Cam (14-117)



44, 54

263 Feed Cam Follower Bracket (14-158)



(Rear View)

264 Ribbon Plate (14-44)



265 Ribbon Feed Cam Follower Stud (14-136)





(Level 1 – Top View)



(Level 2 – Top View)

266 Feed And Lift Wheel Detent Spring (14-48)



(Level 1 Only)

267 Brake Actuating Lever (14-30)



(Level 1 Only)

268 Ribbon Lift Guide Plate (14-207)





LIFT GUIDE PLATE PARALLEL TO SLOT IN CAM FOLLOWER



LIFT GUIDE PLATE OUT OF PARALLEL TOO HIGH AT THE REAR



LIFT GUIDE PLATE OUT OF PARALLEL TOO HIGH AT THE FRONT



LIFT GUIDE PLATE PARALLEL TO SLOT IN CAM FOLLOWER

LIFT GUIDE PLATE PARALLEL TO SLOT IN CAM FOLLOWER

269 Ribbon Lift Control Link (14-128)



270 Load Lever Link (14-147)



271 Pressure Roller Release Arm (14-116)



272 Supply Spool Drag Spring (14-30)



273 Shock Wire (14-26)



274 Drag Lever (14-80)



275 Tracking Post Vertical (14-82)



276 Tracking Post (14-82)



277 Pressure Roller (14-12) **(14-217)**



278 Ribbon Lift Cam (13-58)



Align Slot To Front Edge Of Print Sleeve Keyway 44, 54

279 Centering Spring (13-38)



(Level 1 Only — Top View)

280 Ribbon Feed Plate (13-38)



(Level 1 Only — Top View)

281 Cartridge Guide Lugs (13-38)



(Front View)

282 Cartridge Retaining Springs (13-76)



(Level 2)

283 Ribbon Lift Lever (13-78)



(Level 2 Only)

284 Ribbon Lift Lever Rear Lug (13-78)



(Level 2)

285 Ribbon Lift Lever Front Lug (13-78)



(Level 2)

286 Ratchet Detent Lugs (13-74)



287 Ratchet Detent Lug (13-74)



Ribbon Feed Pawl Engage By 1/2 The Depth Of The Tooth

288 Ribbon Lift Guide Plate (13-37)



289 Ribbon Lift Control Link (13-62)



290 Stencil Lockout (13-65)



(Level 1)

291 Feed Cam Follower Bracket (15-12)



(Rear View)

292 Lift Arm (15-6)



293 Spiked Driver Post (15-61)



(Right Side View)

(Front View)

294 Ribbon Lift Cam (15-17)

Align Slot To Front Edge Of Print Sleeve Keyway



44, 54

295 Feed Cam Follower Eccentric (15-8)



296 Lift Control Lever (15-76)



297 Spread Adjusting Plate (15-22)



298 Lift Height (15-30)



297

299 Lift Arm Lower Stop (15-2)



300 Shock Wire (15-83)



301 Stencil Adjustment (15-76)



302 Swing Arm Lug (15-62)



303 Shock Wire Disengage Lever (15-87)



304 Shock Wire Disengage Lever (15-87)



305 Cartridge Guides (15-86)



306 Cartridge Retaining Springs (15-59)



307 Take-Up Core Interlock (15-59)



308 Load Lever (15-64)



309 Mode Button Grip Clip Position (15-93)



310 Load Lever Spring (15-85)



311 Correcting Keylever Side Play (26-95)



312 Backspace Keylever (01-101)



313 Correcting Keybutton Interlock Front To Rear (26-259)



(Right Side View)

314 Lockout Bail Link (21-546)



(Right Side View)

315 Correcting Keybutton Interlock And Lockout Bail (26-259)



NOTE: Keyboard Lock Interposer Clears Compensator Tube With Switch In ON Position

316 Correcting Keylever Link (26-90)



317 Mode Actuating Bellcrank (26-80)



Check Adjustment On Spacebar And Print Escapement Cam Lobe

318 Trigger Link (26-76)



319 Cable Guide Bracket (26-59)



320 Cable Guide Lug (26-71)



321 Cardholder (26-41)



322 Cardholder (26-41)



323 Left-Hand Ribbon Lift Guide (26-72)



324 Tape Lift Assembly Front To Rear (26-71)



325 Tape Lift Assembly Vertical (26-71)



326 Tape Supply Cradle Fork (26-34)



327 Torque Bar Back-Up Lug (26-55)



(Pre-FTB) *(Bottom View)* *(FTB)*

328 Correcting Torque Bar End Play (26-98)



(Pre-FTB)

329 Torque Bar Stop Bracket (26-89)



(Pre-FTB)

330 Torque Bar Link (Preliminary) (26-86)



331 Lift Actuating Arm (26-62)



(Pre-FTB) *(FTB)*

332 Lift Arm Latch (26-66)



333 Torque Bar Link (Final) (26-86)



334 Tape Feed Cam Follower Front Lug (26-53)



335 Tape Feed Cam Follower Rear Lug (26-45)



336 Guide (26-13)



337 Separator Wire (26-9)



338 Paper Guide Lug (26-20)



339 High Bias Spring (26-34)



340 Margin Rack (09-19)



341 Left Final Stop (09-61)



(NRB/S)

342 Left Final Stop (10-17)



(Top View) (RB/S) (Bottom View)

343 Margin Pitch Link Guide Bracket (10-25)

12-Pitch Mode



344 Margin Rack Gear (10-29)

Hold Rail To Right.
Remove Play In Rack To Left



(Dual Pitch) (Level 1 – Single Pitch)

345 Front Margin Rack Gear Stop (10-25)



(Dual Pitch Only)

346 Lighted Margin Switch (10-112)



(Right Side View) *(Dual-Pitch 670X Only)*

347 Lamp Shield (10-117)



(Front View) *(Dual-Pitch 670X Only)*

348 Lamp Mounting Bracket (10-117)



(Right Side View) *(Dual-Pitch 670X Only)*

349 Lamp Bracket (10-117)



(Rear View) *(Dual-Pitch 670X Only)*

350 Linelock Bracket (09-5)



(Right Side View)

351 Margin Rack (09-71) (10-13)



352 Bellringer Bail Extension (09-80)



353 Bellclapper Bellcrank (09-76)



354 Margin Set Lever Pointer (10-101)



(Dual-Pitch 670X Only)

355 Margin Set Lever Pointer (10-100)



(Dual-Pitch 670X Only)

356 Carrier Pointer Left To Right

(09-3)



(Level 1)

(10-40)



(Level 2)



(Sound Reduction 8XX)
(Single-Pitch 670X)

(30-18)



(Dual-Pitch 670X)

357 Carrier Pointer Parallel (10-108)



358 (Dual-Pitch 670X Only)

358 Carrier Pointer Front To Rear (10-37)



(Level 2)

(30-19)



(8XX Sound Reduction)
(Single-Pitch 670X)

(10-107)



(Dual-Pitch 670X Only)

359 Top Cover Hinge (04-04) (05-04)



360 Top Cover Latches (04-83)



(Level 1)

(05-02)



(Level 2)

361 Cover Mounts (04-251) (04-230)



Check All Other Cover Adjustments And Paper Table

362 Acoustical Filter Hood (30-126)



363 Trigger Link (Dead Key Only) (26-76)



364 Dead Key Rear Cable Clamp (40-11)



Adjust Cable Sheath To Center Of Rear Cable Clamp

365 Dead Key Front Cable Clamp (40-11)



Hold This Adjustment To Low Side Of Spec

366 Dead Key Disconnect Indicator (40-29)



Match Slope Of Keyboard

367 Cable Sheath (40-41)



Two Loops

Dead Key Disconnect, Double Index, External Ribbon Control

368 Dead Key Disconnect Cable Clamp (40-41)



369 Double Index Bellcrank



Cable Cover Flush

Adjust To Trip Index Without Binding Off Latch

(Level 1 Only)

370 Side Frame Clamp



Index Keylever Does Not Bind Off When Depressed

(Level 1 Only)

371 Trip Shaft Clip (20-33)



Slight Pressure On Spring In Double Index Mode

372 Carrier Return Interlock Link (20-35)



373 Tripper (20-39)



(Level 2)

374 Locator (20-45)



Positive Disengagement

(Level 2)

375 Locator (20-44)



Positive Disengagement

(Level 2)

376 External Ribbon Control Bracket (13-91)



Stencil Position

377 Ribbon Lift Control Link (13-63)

High Lift Position



378 Manual Velocity Control Indicator (21-543)



379 Manual Velocity Low Velocity Link (21-550)



380 Manual Velocity Control Link (21-546)



(Top View)

381 Platen Core Lateral Position (49-07)



(Level 1)

(49-109)



(Level 2)

382 Pinwheel (49-08)



Adjust So Pins Are Fully Extended After Passing Through Slot

383 Pinwheel Paper Guide (49-105)



(Large Rollers) *(Small Rollers)*

384 Cardholder (49-21)



385 Cardholder Mounting Bracket (22-164) (22-167)



386 Vane Return Spring (41-07)



387 Shift Sensing Vane Bellcrank (41-09)



388 Rear Cable Clamp (41-25)



389 Front Cable Clamp (41-18)



390 Center Cable Clamp (41-25)



SERVICE CALL PROCEDURE

Preventive Maintenance MUST BE PERFORMED On Each Service Call.

Each Service Call Must Include:

A. Note operator comments.
B. Identify and correct operator complaint.
C. Initial functional check — Look for parts wear, marginal adjustments, and proper lubrication.

With Special Attention To:

1. Character Selection
2. Keyboard
3. Carrier And Rocker
4. Cycle Shaft/Gear Train
5. Operational Area (Carrier Return, Backspace, Tab, Spacebar, Index)
6. Shift

D. Repair, replace parts, and lubricate as necessary.
E. *Perform electrical safety check.
F. When necessary, remove covers and clean.
G. All areas visible to the operator (e.g., rubber parts, cardholder, element/type, and covers) must be clean and in good repair.
H. Perform final functional check.
I. Work performed should be discussed with the operator and must be recorded on the history card.

*A visual or physical inspection must be made of the primary wiring on the machine during each service call. **Defects in any electrical component must be replaced immediately!** Do not wait until the next service call. Always exercise care when working on electrical areas of the machine. Be certain that no action on your part makes the product unsafe or exposes the customer to hazards.

LUBRICATION

The "Selectric" Typewriter will not operate dependably and reliably if it is not thoroughly and properly lubricated.

Use IBM No. 10 oil on the following:

a. Print shaft wipers
b. Selector cam shaft bearing
c. Margin rack bearing
d. Margin stops
e. Carrier shoe
f. Rotate detent guide, upper and lower ball sockets, tilt detent pivots
g. Motor
h. Selection bail rollers
i. Index pawl assembly
j. All links and clevises at both ends
k. Ribbon feed and reverse plate
l. Backspace intermediate lever
m. Differential assemblies
n. All functional parts and pivots in operational box assembly
o. Tilt arm pivot and rotate link stud
p. Rotate arm pivot and rotate link pivot studs
q. Carbon ribbon drive spring and bearing
r. Power frame center bearing
s. Platen bushings
t. Tilt latch mounting stud and bellcrank
u. All other rotating or pivoting members at the bearing area which are not excepted in the following lists:

Use IBM No. 23 grease on the following:

a. Operational ratchets
b. Keylever return springs
c. Interposer latch springs
d. Ribbon lift control lever
e. Linelock bracket
f. Filter shaft flutes
g. Operational keylever pawl guide studs
h. Tape guide
i. All cams on print sleeve
j. Ball joint
k. Cycle clutch and shift clutch springs
l. Feed roll bearing
m. Cycle clutch restoring cam
n. Low velocity latch contacts
o. All sliding parts not excepted
p. All selective ribbon takeup gears
q. Selective ribbon lift guide sliding members
r. Correcting tape feed bellcrank latching surface
s. Torque limiter spring
t. Element (or silicone grease)

DO NOT LUBRICATE:

a. Shift brake (braking surface)
b. Gear train
c. Carrier return and tab pinions

FUNCTIONAL CHECK

MISCELLANEOUS

1. Visual Inspection
2. ON/OFF Switch, Keyboard Lock
3. Margin Set
4. Margin Release
5. Linelock And Bell
6. Scales And Carrier Indicator
7. Switch Pitch Lever (Dual Pitch)
8. Index
9. Shift Lock
10. Margin Lights

PAPER HANDLING

1. Paper Insertion
2. Paper Release
3. Multiple Copy Control
4. Detent Release
5. Platen Variable

CARRIER MOVEMENT (Check all items in both pitches on dual-pitch machines.)

1. Spacebar And Escapement
2. Half Backspace
3. Backspace
4. Carrier Return
5. Express Backspace
6. Tab

RIBBON OPERATION

1. Ribbon Feed
2. Ribbon Lift Pattern
3. Ribbon Path And Tracking
4. Stencil Position
5. Ribbon Reverse (Fabric Ribbon)

PRINT

1. Strike Up — Check For:
    - a. Impression
    - b. Selection
    - c. Alignment
    - d. Keyboard Touch
    - e. Shift
2. Repeat Character
3. Impression Control

CORRECTING MECHANISM

1. Type several characters.
2. Depress correcting key.
    - a. Carrier should backspace once.
3. Restrike last character.
    - a. Character removed (lift-off tape) or character covered (cover-up tape)
    - b. No escapement
4. Type new character.
    - a. Same position as original character.
    - b. Normal escapement and print should resume.
5. Repeat steps 1 through 4.
    - a. No overlap of characters on correcting tape.

ELECTRICAL SAFETY CHECK

For both Per Call and Service Agreement machines, a visual or physical inspection must be made of the primary wiring on the machine during each service call.

VISUAL CHECK FOR ELECTRICAL HAZARDS

1. Linecords that have become damaged must be replaced.
2. Wires that are cut, rubbing on mechanical parts, or loose in the machine, must be replaced or relocated. Use cable tie or something similar to hold loose wires.
3. Whenever a switch cover, wire retainer, or safety shield has been removed for servicing, it must be reinstalled when service is completed.
4. Wire connections should only be replaced with wire nuts for crimp-on connectors. Neither tape nor insulating splice should be used.
5. Inspect all linecords that pass through holes in metal desks for cuts or markings. When necessary, grommets or tape should be placed over these edges that come in contact with the linecord.
6. Check to ensure:
    - a. that all double-insulation components are installed
    - b. that insulating paper isolates capacitors from a machine frame on two-wire products
    - c. that no parts, such as paper clips, staples, etc., have become jammed between electrical components and the machine frame, grounding that component to the machine frame. Check the particular product CEMs for a description of the required components.
7. Modifications made by customers to their machines, which expose Customer Engineers to electrical hazards, must be reported to your management.

CAUTION: Unplug the machine before working on electrical area.

A quick visual check of the electrical components in equipment during each service call will reduce the possibility of exposing a customer or CE to electrical shock. **Defects in any electrical component must be replaced immediately!** Do not wait until the next service call. Always exercise care when working on electrical areas of the machine. Be certain that no action on your part makes the product unsafe or exposes hazards to the customer.

BROKEN TAPES CHECK

Rotate Tape

1. Rotate detent clearance (skirt)
2. Print shaft timing
3. Shift interlock adjustments
4. Defective rotate arm and shift arm pulleys
5. Tape guide
6. Negative latch clearance insufficient
7. Latch links: too long/too short
8. Popping latches
9. Latch angle
10. Broken or sticking rotate spring
11. Binding on non-greased type element
12. Shift arm pulley
13. Chips or defects in rotate pulleys
14. Rotate pulley key
15. Loose screw in differential bracket

Tilt Tape

1. Detent to tilt ring clearance
2. Burrs on tilt pulleys
3. Binds in tilt ring
4. Sector gear
5. Print shaft timing
6. Tilt pulley spring (off or broken)
7. Loose detent follower
8. Tilt tape/carrier shoe eccentric stud

Type Element Arrangements, Ribbon Applications

STANDARD U.S. TYPE ELEMENTS 7XX 8XX

Tilt Latches Used	Rotate											Type Element Positions
	R-5	R-4	R-3	R-2	R-1	Home	R+1	R+2	R+3	R+4	R+5	
T-0	[/]	#/3	&/7	*/8	$/4	Z/z	@/2	%/5	¢/6	)/0	(/9	Tilt T-0
T-1	X/x	U/u	D/d	C/c	L/l	T/t	N/n	E/e	K/k	H/h	B/b	T-1
T-2	M/m	V/v	R/r	A/a	O/o	°/!	./.	"/,	I/i	S/s	W/w	T-2
T-1, T-2	G/g	F/f	:/;	·/,	?//	J/j	+/=	P/p	Q/q	Y/y	—/-	T-3
	-5	-5 R-1	-5 R-2	-5 R-1 R-2	-5 R-2 R-2A	HOME	R-1	R-2	R-1 R-2	R-2 R-2A	R-1 R-2 R-2A	Rotate Latches Used

STANDARD U.S. 96 TYPE ELEMENTS

Tilt Latches Used	Rotate												Type Element Positions
	R-6	R-5	R-4	R-3	R-2	R-1	Home	R+1	R+2	R+3	R+4	R+5	
T-0	?//	=/3	(/9	*/8	$/4	¢/6	)/0	@/2	%/5	&/7	³/²	Z/z	Tilt T-0
T-1	+/=	¶/§	U/u	K/k	B/b	C/c	E/e	T/t	S/s	I/i	"/,	:/;	T-1
T-2	°/±	¼/½	H/h	X/x	A/a	N/n	R/r	O/o	D/d	W/w	M/m	V/v	T-2
T-1, T-2	'/,	[/]	G/g	L/l	F/f	Y/y	P/p	Q/q	J/j	./.	!/1	—/-	T-3
	-6	-6 R-1	-6 R-2	-6 R-1 R-2	-6 R-2 R-2A	-6 R-1 R-2 R-2A	HOME	R-1	R-2	R-1 R-2	R-2 R-2A	R-1 R-2 R-2A	Rotate Latches Used

FILL IN FOR OTHER TYPE ELEMENTS 7XX 8XX

Tilt Latches Used	Rotate											Type Element Positions
	R-5	R-4	R-3	R-2	R-1	Home	R+1	R+2	R+3	R+4	R+5	
T-0	/	/	/	/	/	/	/	/	/	/	/	Tilt T-0
T-1	/	/	/	/	/	/	/	/	/	/	/	T-1
T-2	/	/	/	/	/	/	/	/	/	/	/	T-2
T-1, T-2	/	/	/	/	/	/	/	/	/	/	/	T-3
	-5	-5 R-1	-5 R-2	-5 R-1 R-2	-5 R-2 R-2A	HOME	R-1	R-2	R-1 R-2	R-2 R-2A	R-1 R-2 R-2A	Rotate Latches Used

FILL IN FOR OTHER TYPE ELEMENTS

Tilt Latches Used	Rotate												Type Element Positions
	R-6	R-5	R-4	R-3	R-2	R-1	Home	R+1	R+2	R+3	R+4	R+5	
T-0	/	/	/	/	/	/	/	/	/	/	/	/	Tilt T-0
T-1	/	/	/	/	/	/	/	/	/	/	/	/	T-1
T-2	/	/	/	/	/	/	/	/	/	/	/	/	T-2
T-1, T-2	/	/	/	/	/	/	/	/	/	/	/	/	T-3
	-6	-6 R-1	-6 R-2	-6 R-1 R-2	-6 R-2 R-2A	-6 R-1 R-2 R-2A	HOME	R-1	R-2	R-1 R-2	R-2 R-2A	R-1 R-2 R-2A	Rotate Latches Used



Tilt



Rotate

APPLICATIONS RECOMMENDATIONS FOR IBM RIBBONS

	IBM General Purpose Fabric Ribbons	Film Carbon Ribbons (All)	OCR Film Carbon Ribbon	"Special" Film Carbon Ribbon (5122)	IBM Tech III Ribbon	IBM Correctable Film Ribbon
TYPING APPLICATIONS						
Correspondence		x			x	x
Statistical Correspondence	x	x			x	x
Specification Writing	x	x			x	x
Medical Reports	x	x			x	x
Executive Correspondence		x			x	x
Routine Correspondence	x	x			x	x
Typing on Hard-to-Image Originals	x		x	x	x	
Ex.: Engineering Drawings						
Optical Character Recognition		x	x		x	
Manifolding					x	
** Speech Writing	x	x			x	
Negotiable Instruments	x	x		x	x	
(checks, stocks, etc.)						
* Erasable Bond Papers	x		x	x	x	
REPRODUCTION APPLICATIONS						
Heat Transfer Copying	x	x	x	x	x	x
Transfer Electrostatic Reproduction	x	x	x	x	x	x
Direct Electrostatic Reproduction	x	x	x	x	x	x
Offset Masters (Direct to Plate)	x	x		x	x	
Offset Masters (Copier Process)	x	x	x	x	x	x
Offset Masters (Photo Process)	x	x			x	
Stencil Writing (Mimeograph)						
Diazo Process (Ozalid or Bruning)						
Spirit Duplication						
(Hecktographic or Ditto)						

* The receptivity of the surface of these materials vary widely and care must be used in the selection of a specific material, typestyle and ribbon to produce the best result. When in doubt, let the customer try it first.

** Best results with Orator element are obtained by using IBM Tech III Ribbon.



Also Refer To TII/CSI And Latest CEM'S

Edge Definition Decreases As Number Of Copies Increases

Make All Adjustments According To APM

DANGER: 115 VAC may be present.

LINECORD VOLTAGE CHECK

1. Make sure the linecord is properly connected.
2. Connect the VOM to the ON/OFF switch.
3. If 115 VAC is not present, check the following:
    - a. Proper voltage at the power outlet
    - b. Linecord



(Rear View)

DANGER: 115 VAC may be present.

SWITCH VOLTAGE CHECK

1. Connect the VOM to the solderless connector at the points shown.
2. If 115 VAC is not present, check the following:
    - a. ON/OFF switch
    - b. Solderless connector



(Rear View)

TRANSFORMER VOLTAGE CHECK

1. Connect a VOM to the anchor point and the O/P of the lamp selector switch.
2. If 2.3 to 3.0 VAC is not present, check the following:
   - a. Solderless connector
   - b. Transformer



(Left Side View)

12 PITCH VOLTAGE CHECK

1. Connect a VOM to the anchor point and to the N/O connector.
2. If 2.3 to 3.0 VAC is not present, check the following:
   - a. Lamp selector switch
   - b. 12-pitch lamp
   - c. 12-pitch lamp wires



(Left Side View)

10 PITCH VOLTAGE CHECK

1. Connect a VOM to the anchor point and to the N/C connector.
2. If 2.3 to 3.0 VAC is not present, check the following:
   - a. Lamp selector switch
   - b. 10-pitch lamp wires
   - c. 10-pitch lamp



(Left Side View)

MOTOR WIRING DIAGRAMS



3-Wire Shaded Pole Motor Diagram



Double-Insulated Shaded Pole Motor Diagram



2-Wire Double-Insulated Shaded Pole Motor Diagram
(Single Pole Switch)



3-Wire Capacitor – Start Motor Diagram



Double-Insulated Capacitor – Start Motor Diagram



Dual-Pitch 3-Wire Double Insulated Shaded Pole Motor
"Selectric" III



Dual-Pitch 2-Wire Double Insulated Shaded Pole Motor
"Selectric" III

BACKSPACE
(NR B/S)

MECH. CODE
01

FOR ROTARY BACKSPACE PARTS SEE MECH 24







CARRIER

MECH. CODE
02

Predual Impression Machines

This stud, P/N 1124176, is used as a replacement part on all machines not equipped with dual impression which have the original "non-faced" carriers.



Early Dual Impression Machines

This stud, P/N 1175054, must be used on the early dual impression machines. The follower, P/N 1141619, must also be replaced to ensure compatibility. This procedure is necessary because the early DI carriers were "non-faced." Note: Use washer, P/N 1164290, to reduce side play.

Part No.	Description
1175054	Stud, Fol. Mtg.



Predual Impression Machines With New Carrier

This stud P/N 1164865 and nut, P/N 6503, must be used with a carrier change on all machines not equipped with dual impression. This is necessary because all field replacement carriers are "faced" and do not have a setscrew hole for mounting the original stud.

Part No.	Description
1164865	Stud, Fol. Mtg.
6503	Nut



Current Level Machines

This stud, P/N 1164878 and nut, P/N 6503, can be used on all dual impression carriers that are "faced." It must be used with the new print cam follower, P/N 1141619.

Part No.	Description
1164878	Stud, Fol. Mtg.



CARDHOLDER CHARTS

MECH 26 CORRECTING



MECH 49 PIN FEED
9XX-THAI-W.T.



MECH 22 PAPER FEED

UNIVERSAL BRACKET (SNAP-IN)



UNIVERSAL CARDHOLDER
(BOLT ON)



PIN FEED CARDHOLDER





8/9XX W.T.


302
301
300
303-ASM. FOLDER PRINT SHIELD
304-PACK WITH CARD HOLDER ASSEMBLIES

MECH. CODE
02

CARRIER

DUAL IMPRESSION



PRE DUAL IMPRESSION



ROCKER
(GEARLESS TYPE TILT)

MECH. CODE
02



336 TILT PULLEY B/M
528 ROCKER ASM. B/M PRIOR TO D.I.
535 DETENT SUPPORT & LEVER B/M
540 DUAL IMP YOKE & ROCKER B/M

ROCKER
(GEAR TYPE TILT)

MECH. CODE
02



MECH. CODE
03

CARRIER RETURN
(R B/S)



MECH. CODE
03

CARRIER RETURN
(NR B/S)

SELECTRIC II



SELECTRIC II EARLY LEVELS

SELECTRIC LATE LEVELS



CARRIER RETURN

(NR B/S)

MECH. CODE
03



COVERS & MOUNTING (7XX)

MECH. CODE
04



PAINT-SEE MECH 05-500
91-PAPER TABLE B/M
56-DUST COVER
95-B/M SOUND INSULATION
100-B/M COVER LATCH ADAPTOR
304-B/M COVERS (SEE CHART IN PN/PL)
285-B/M SHOCK MOUNTS
310-B/M SET OF BOTTLES W.T.

MECH. CODE 04

COVERS & MOUNTING (7XX)



MECH. CODE 05

COVERS & MOUNTING (8XX) (9XX)


CORR. SE COVER B/M SEE MECH. 26-103
101-INSULATION B/M
102-DUST COVERS
126-LOGO REAR
107-8X3, 8X5, COVER B/M 10P, 12P, & DP SEE COVER CHART IN PN/PL
500-PAINT
23-COVER HINGE B/M
62-W.T.
04-312
SEE MECH. 04
104-TOP COVER SEE CHART IN PN/PL
LEVEL I
METAL BRACKET
W.T. LATCHES
105-CENTER SECTION SEE CHART IN PN/PL

COVERS & MOUNTING (8XX) (9XX)

MECH. CODE
05



14-SELF TAPPING

106-BOTTOM COVER SEE CHART IN PN/PL

FRAME BOLT DOWN

COVER BOLT DOWN

COVER (670X)

MECH. CODE
05



171-B/M COMPLETE COVERS SEE CHART IN PN/PL

200-COVER HINGE B/M

172-INSULATION B/M

MECH. CODE
06

ESCAPEMENT
(NRB/S)



MECH. CODE
07

ESCAPEMENT HALF/BACKSPACE
(RB/S)



MECH. CODE

FRAMES

MECH. CODE
08



MECH. CODE
09

MARGINS

(NR B/S)

LEVEL 4



7XI



SELECTRIC II



MECH. CODE
09

MARGINS

(NR B/S)

LEVEL 3



LEVEL 2



LEVEL I LONG CARRIAGE



LEVEL I



105 - B/M CARRIER POINTER 7XX
125 - MARGIN LEVER ASM.
126 - B/M MARGIN RACK
133 - B/M MARGIN PIVOT
150 - MARGIN RACK ASM. INCL. REF. 125

LINELOCK & BELL

MECH. CODE
09



MARGINS

(RB/S)

MECH. CODE
10



MECH. CODE
11

U.S. MOTOR & DRIVE
(SHADED POLE)



52-LINE CORD B/M
66-SWITCH CONVERSION B/M
73-B/M MOTOR PULLEY
90-B/M 50 HZ CONVERSION
43-HUB & PAWL ASSM. COMP.

MECH. CODE
11

U.S. MOTOR & DRIVE
(SHADED POLE)

SELECTRIC III



607-WIRE TIES FOR SECONDARY TRANSFORMER LEADS

U.S. MOTOR & DRIVE
(CAPACITOR START)

MECH. CODE
11



W.T. MOTOR & DRIVE
(NETHERLANDS – SHADED POLE)

MECH. CODE
11



MECH. CODE
11

W.T. MOTOR
(NETHERLANDS — FIELD USE PARTS)

BI-VOLTAGE SWITCH FRANCE



FIELD USE PARTS
FOR CAPACITOR MOTOR



MECH. CODE
11

W.T. MOTOR & DRIVE
(NETHERLANDS — DOUBLE INSULATION)



W.T. MOTOR & DRIVE
(CANADIAN – SHADED POLE)

MECH. CODE
11



W.T. MOTOR & DRIVE
(CANADIAN – DOUBLE INSULATION)

MECH. CODE
11



73 – B/M MOTOR PULLEY
360 – LABEL, ADDITIONAL
365 – NOISE REDUCTION PACKAGE
370 – B/M MOTOR

FOR: UK
IRELAND
SOUTH AFRICA
AUSTRALIA

MECH. CODE
12

PLATEN



"SELECTRIC"



25	B/M 24T RATCHET CONVERSION
30	B/M 54T RATCHET
33	B/M LINE POSITION RESET LEVER

MECH. CODE
13

FABRIC RIBBON



64 - LEVEL I RIBBON FEED ASM.
80 - LEVEL 2 RIBBON FEED ASM.
81 - B/M STENCIL LOCKOUT
02 - 130 - B/M CARRIER & ROCKER ASM. 7/84X WITH EXTERNAL RIBBON CONTROL
02 - 130 - B/M CARRIER & ROCKER FAB.RIB. COMP.



EXT. RIBBON CONTROL NOT FIELD INSTALLABLE

500-B/M CARRIER AND ROCKER EXT. RIB. CONTROL



FILM RIBBON

MECH. CODE
14



LOCK DOWN FEATURE

SEE MECH 09

02-130 B/M CARRIER & ROCKER ASM FABRIC RIBBON COMPLETE
175-B/M FABRIC TO FILM
249-PLATE ASM COMPLETE
256-B/M PRESSURE ARM

FILM RIBBON

MECH. CODE
14



PLATE ASM COMPLETE NOT AVAILABLE

OBSOLETE

175-B/M FIELD CONVERSION FABRIC TO FILM RIBBON
180-B/M FIELD CONVERSION FILM TO FABRIC RIBBON

MECH. CODE
15

SELECTIVE RIBBON





103-RIBBON FEED GEARS B/M
151-RIBBON PLATE ASM
506-SPREAD PLATE & FOLLOWER B/M

LEVEL 1





FOR U.S. CALL REPORTING
502-TECH. III RIBBON
503-FILM RIBBON

MECH. CODE
16

SHIFT

LEVEL 3 SINTERED STEEL

NON-REFERENED PARTS IN MECH 16 NOT AVAILABLE. ORDER REF. 300 B/M AND REF. 220 B/M WHEN REPLACING ANY OF THESE PARTS







300-B/M SHIFT ARM & BEARING ASM.
220-B/M SINTERED STEEL CONVERSION

SHIFT

MECH. CODE

16

LEVEL 2 7X1 PLASTIC CAM



LEVEL 1 XX3 AND XX5 STEEL CAM



LEVEL 2 XX3 AND XX5 PLASTIC CAM



LEVEL 1 7X1 STEEL CAM



NON-REFERENCED PARTS NOT AVILABLE ORDER REF. 300 B/M AND REF. 220 B/M WHEN REPLACING ANY OF THESE PARTS

SPACEBAR

MECH. CODE

17

LEVEL 3



W.T.



W.T.



"SELECTRIC" II TYPEWRITER RB/S





MECH. CODE
17

SPACEBAR

LEVEL 2



LEVEL 1



MECH. CODE
18

TAB
(NR B/S)



130 - R.H. TRANSPORT PULLEY & BRKT ASM. COMP.
131 - B/M FIELD REPLACEMENT NEW STYLE TRANSPORT PULLEYS
150 - B/M TAB LINKAGE AND TORQUE BAR 8X3 - 8X5 LEVEL 2
153 - B/M TAB LEVER ASM L-3

TAB
(NR B/S)

MECH. CODE
18

LEVEL 2 TAB LEVER



LEVEL I TAB LEVER



TAB PULLEY AND BRACKET



FOR PARTS NOT REFERENCED ORDER B/M 130-R.H. TRANSPORT PULLEY & BRKT ASM. COMPLETE

7X3-7X5 TAB BELLCRANK LEVEL I



OBSOLETE PARTS - SEE REF 24



200-B/M TAB KEYLEVER LINE LOCK



7 X I



LEVEL I

LEVEL 2



LEVEL I ESCAPEMENT SHAFT



TAB
(RB/S)

MECH. CODE
19



152-B/M CONVERSION FROM ALL STEEL TO DUAL TRANSPORT

ALL STEEL TRANSPORT

150-B/M TAB LINKAGE AND TORQUE BAR 8X3-8X5 LEVEL 2

152-B/M CONVERSION FROM ALL STEEL TO DUAL TRANSPORT

LEVEL I TAB TORQUE BAR & LINKAGE

LEVEL I

8X5 TAB TORQUE BAR LINKAGE 9X5 W.T.

MECH. CODE
20

INDEXING
(A-FRAME)



PLATEN INDEXING PARTS SEE PLATEN INDEXING CHART IN PN/PL

500-B/M 54 TOOTH INDEXING

511-B/M FIELD REPLACEMENT PAWL CARRIER MTG STUD INCLUDES REF 509 & 510

517-B/M DETENT ASM 54 TOOTH ECC OVERTHROW





499-B/M 24 T

501-B/M 45 & 48T

MECH. CODE
20

INDEXING
(TIE-ROD)







REMOVE DOTTED PORTION FOR EARLY LEVEL MACHINES

499-B/M 24 TOOTH INDEXING

501-B/M 45 TOOTH INDEXING

500-B/M 54 TOOTH INDEXING

516-B/M 54T TO 27T CONVERSION

INDEXING
(DOUBLE)

MECH. CODE
20

LEVEL 2



50 F.L B/M DOUBLE INDEX

LEVEL 3







LEVEL 1 - 2, 2½, 3 LINES



505-B/M INDEX 2, 2½, 3 LINES

W.T. INDEXING

MECH. CODE
20

LEVEL 1



8XX/9XX







500 B/M INDEX CONVERSION

2 POS.





3 POS.

MECH. CODE
21

KEYBOARD



500-B/M AVC INHIBITOR

PARTS NOT SHOWN HERE ARE COMMON PARTS & ARE INCLUDED IN R.H. DRAWING

554-B/M MANUAL VELOCITY CONTROL

MECH. CODE
21

KEYBOARD



31-SEE TYPE CATALOG F/N 241-5687 PCE-001 WT

110-FORMER LEVEL SPRING MAY BE USED HERE IF A SPRING FINGER BREAKS

100-B/M KEYBOARD
103-KEYBOARD INSULATION
105-KEYLEVER REPEAT ROW-E.W.T.
106-KEYLEVER REPEAT ROW-D.W.T.
107-KEYLEVER REPEAT ROW-C.W.T.
108-KEYLEVER REPEAT ROW-B.W.T.
700-715-B/M'S KEYBUTTONS

30-FIELD REPLACEMENT B/M

KEYBOARD

MECH. CODE
21



KEYBOARD
(DUAL IMPRESSION)

MECH. CODE
21



MECH. CODE
22

PAPER FEED
(A-FRAME)



228-PAPER FEED ASM.
229-B/M, CONVERSION

MECH. CODE
22

PAPER FEED
(TIE-ROD)



LEFT HAND SECTION LEVEL-2

FOR PIN FEED SEE MECH 49

216-SEE CARD HOLDER CHART

219-PAPER BAIL B/M
228-PAPER FEED ASM B/M

PAPER FEED
(TIE-ROD)

MECH. CODE
22



LEVEL 1



PAPER FEED
(TIE-ROD)

MECH. CODE
22



LEVEL 1



LEVEL 1
LONG CARRIAGE



LEVEL 1



LEVEL 2



LEVEL 3



MECH. CODE
23

SELECTION



435- B/M CYCLE CLUTCH

437- B/M CYCLE SHAFT

470- B/M GEAR TRAIN

500- B/M CYCLE SHAFT L-2 W.T.

MECH. CODE
23

SELECTION



SELECTION

MECH. CODE
23



ROTARY BACKSPACE/EXP BACKSPACE

MECH. CODE
24



MECH. CODE
25

OPERATIONAL CONTROL



MECH. CODE
25

OPERATIONAL SHAFT ASSEMBLY



CORRECTING

MECH. CODE
26



34-CRADLE ASM. B/M
102-CARRIER & ROCKER ASM.
106-RIBBON PLATE ASM.
13-TAPE FEED B/M

CORRECTING

MECH. CODE
26



103-B/M COVERS (VENT GRILL NOT INCL.) SEE CHART IN PN/PL
104-B/M PAPER BAIL
107-REAR LOGO
130-B/M FRONT CARRIER SUPPORT & TORQUE BAR

MECH. CODE
30

SOUND REDUCTION

31-FIELD INSTALL SOUND PACKAGE B/M 8x3-8x5
32-COMPLETE COVER B/M SOUND PACK (SEE CHART IN PN/PL)
50-B/M HOOD SOUND REDUCTION W.T.
100-B/M COVERS W.T.



MECH. CODE
30

SOUND REDUCTION

165-FIELD INSTALLED B/M SOUND PACKAGE
163-COMPLETE COVER B/M SOUND PACK, SEE CHART IN PN/PL



CARD HOLDING PLATEN

MECH. CODE
39



NOTE: REFER TO STD. PLATEN FOR PARTS NOT REFERENCED

DEAD KEY

MECH. CODE
40



50-DEAD KEY DISCONNECT B/M FIELD INSTALLED ONLY ON MACHINES WITH U.S. SN. BEGINNING WITH 5 OR 9 OR ANY SELECTRIC II

MECH. CODE
40

W.T. DEAD KEY
(THAILAND)

PARTS NOT SHOWN HERE ARE COMMON PARTS
AND ARE INCLUDED IN DEAD KEY DRAWING MECH. 40



MECH. CODE
41

SHIFT SENSING



WORLD TRADE VELOCITY VANE



HANDICAPPED ATTACHMENTS

MECH. CODE
45



30-B/M PAPER ROLL HOLDER
44-B/M TEAR OFF BLADE



34-B/M KEYBOARD REST

HANDICAPPED ATTACHMENTS

MECH. CODE
45



12-B/M ARM REST

MECH. CODE **49**

PIN FEED PLATEN

LEVEL 1



MECH. CODE **49**

PIN FEED PLATEN

LEVEL 2



150-WT. B/M PAPER BAIL
117-SPECIAL LENGTH CORES
130-PINWHEEL ASSEMBLIES
131-PINFEED PLATEN B/M'S-ORDER CORE, KNOBS, CARD HOLDER AND BRACKET

W. T. OVERHEAD PIN FEED PLATEN

MECH. CODE
49



STROKE COUNTER

MECH. CODE
51



MECH. CODE
65

W.T. PACKING PARTS



W.T. PACKING INSTRUCTIONS

WORLD TRADE PACKING INSTRUCTIONS

1. Position the carrier against the left-hand side frame of the machine.
2. Put the machine in upper case and trip position No. 3 keylever.
3. Fit the two platen detent packing pieces (Ref. 109) in position. (See figure.)
4. Attach tape to the top cover. (See figure.) Use P/N 7340090 or similar quality tape. On sound hood machines, tape from front of acoustical hood to center cover.
5. Tilt the machine on its back cover and place grommets (Ref. 106) into the bottom cover.
6. Fit the mounting studs (Ref. 107) in the bottom of the power frame; five studs in 7X1, seven studs in 7X3/7X5, and four studs in 8XX machines.
7. Put a plastic spacer (Ref. 105) on each mounting stud.
8. Place the pallet (Ref. 102) over the mounting studs (8XX/9XX only).
9. Place hair pad (Ref. 104) over the mounting studs.
10. Fit a washer (Ref. 111) on each mounting stud.
11. Tighten a nut (Ref. 103) on each mounting stud.
12. Place the machine and hair pad into the typewriter box.
13. Place the linecord to the rear of the box.
14. Assemble the liner (Ref. 108) and position it around the machine.
15. Put accessory bag (Ref. 121) between the liner and the inside of the box.
16. Place cover plate (Ref. 110) on top of the liner and close the box.
17. Seal the lid with heavy-duty packing tape.

APPROXIMATE WEIGHT OF MACHINE/PACKING

Model		**Model**	**Selective**	**Fabric**
7X1	14.5 kg	8X3	16.5 kg	16.25 kg
7X3	16.5 kg	8X5	17.5 kg	17.25 kg
7X5	17.5 kg	8Y3	16.75 kg	16.25 kg
		8Y5	17.75 kg	16.25 kg
Packing	6.0 kg	Packing	6.75 kg	

Approximate Inside Size Of Box

Length	780 mm
Width	540 mm
Height	320 mm

W.T. PACKING INSTRUCTIONS

WORLD TRADE UNPACKING INSTRUCTIONS

1. Open the top of the box and remove the cover plate (Ref. 110).
2. Remove the liner (Ref. 108).
3. Lift the machine and hair pad (Ref. 104) out of the box.
4. Tilt the machine and hair pad so it rests on the back cover.
5. Remove the packing nuts (Ref. 103) and washers (Ref. 111).
6. Remove the hair pad (Ref. 104), washers (Ref. 111), and pallet (Ref. 102).
7. Remove plastic spacers (Ref. 105), mounting studs (Ref. 107), and grommets (Ref. 106).
8. Install the three nylon desk feet (Ref. 112) with screws (Ref. 113) from the accessory bag (Ref. 121).
9. Place the machine in operating position and remove tape from the top cover and carrier.
10. Remove the platen detent packing pieces (Ref. 109).
11. The machine is now ready for the preinstallation check.

BOLT DOWN INSTRUCTIONS

BOLT DOWN INSTRUCTIONS – DROP CENTER DESKS

1. Install four mounting feet – P/N 1128485 for "Selectric" Typewriters or P/N 1205981 for "Selectric" II and III Typewriters or Correcting "Selectric" II and III Typewriters – to power frame.
2. Place a small amount of grease on the feet just around the outside of the threaded holes.
3. Set typewriter down in the correct position on the desk. Lift typewriter off the desk. The position of the holes to be made can now easily be seen.
4. Use a drill to make four holes and bolt machine to desk. See C-D Catalog, Code 204, Ref. 67 for mounting bolts.
5. CAUTION: The two front bolts must have some clearance between the bolt heads and the desk bottom. They must not pull down on the feet or the power frame may twist. The two rear feet may be tightened.

COVER BOLT DOWN

1. Remove machine from covers.
2. Place bottom cover in correct position on desk.
3. With a cover adapter in each of the two center holes of the bottom cover, mark where to drill the hole. On the "Selectric" II Typewriter, use spacer between adapter and bottom cover.
4. Use proper length of bolt and fasten the bottom cover to the desk. To find out which bolt to use, add 1/2" (12.70 mm) to the thickness of the desk.

CAUTION: Bolting a machine down by other than these procedures can cause an electrical safety hazard or machine failure. An excessively long bolt could interfere with the motor windings or other inner mechanisms of the machine.

MECH. CODE
65

U.S. PACKING PARTS



U.S. PACKING INSTRUCTIONS

PACKING INSTRUCTIONS

1. Position the carrier all the way to the right, latch out tab and attach Minnesota Mining Y-9035 or similar tape as shown in Mech. 765.
2. Place Minnesota Mining Y-9035 or similar tape on top cover as shown.
3. Place four rubber grommets under the bottom of the typewriter case as shown.
4. Use wing nut screws to mount the pallet to the machine.
5. Place hair pad in bottom of the box and insert machine.
6. Place liner around the machine and place cord to the back of the liner with Minnesota Mining Y-9035 or similar tape.
7. Insert chipboard tray as shown and seal the carton with tape.

CAUTION: Do not excessively tighten the front right-hand wing nut screw.

UNPACKING INSTRUCTIONS

1. Open carton by pulling tear tape completely around four sides. Remove top part of the box. Remove top cardboard chipboard tray. Lift out liner by moving the sides away from the platen knobs and lift machine out of the tray.
2. Tilt machine and pallet so the machine rests on the back cover.
3. Remove the four thumb screws. These can normally be turned by hand, but, if necessary, use a pencil as an additional lever.
4. Remove pallet board and plastic spacers.
5. Remove rubber grommets from the five mounting holes in the machine bottom cover (seven on the 7X5 and 8X5).
6. Install the four nylon spacers found in the plastic accessory bag into four of the mounting holes from which the thumb screws were removed.
7. Set the machine down and remove the tape, holding the top cover and the type carrier.
8. The machine is now ready for preinstallation checkout.

APPROXIMATE MACHINE AND CARTON WEIGHT AND SIZE

7X1 – Size 14" (355.6 mm) Deep, 15" (381.0 mm) Wide
7X5, 8X5 – Size 14" (355.6 mm) Deep, 20" (508.0 mm) Wide

Model 7X1	32 lbs.	(14.5 kg)
Models 7X3, 8X3	35 lbs.	(16.5 kg)
Models 7X5, 8X5	37 lbs.	(17.5 kg)
Carton 7X1	10 lbs.	(4.5 kg)
Cartons 7X5, 8X5, 670X	14 lbs.	(6.35 kg)

CAUSE OF FAILURE	CODE
Beat The Operation	24
Bent/Warped	01
Binding/Sticking	02
Broken/Cracked	03
Burned/Pitted/Burred	04
Card/Tape Jam	05
Dirty/Corroded	06
Flicking	25
Loose/Solder Connector	07
Low Contrast	28
Lubrication	08
Noise (Electrical)	27
Noise (Mechanical)	09
No Trouble Found	19
ON/OFF Registration	10
Open	11
Operator Error	26
Operator Preference*	22
Other	20
Out Of Adjustment	12
Out Of Alignment	13
Shorted/Grounded	14
Sound Distortion	23
Standby	21
Stripped	15
Wiring Defects	16
Weak	17
Worn	18

**Operator Preference — Adjustment due to operator opinion which is not a malfunction of the machine.*

MACHINE IDENTIFICATION CODES

"SELECTRIC" TYPEWRITER – PRODUCT CODE 21

1st Digit – 7

2nd Digit – 1 – Film Ribbon
2 – Fabric Ribbon

3rd Digit – 1 – 8-1/2" writing line
3 – 11-1/2" writing line
5 – 13" writing line

"SELECTRIC" II AND CORRECTING "SELECTRIC" II TYPEWRITERS – PRODUCT CODE 26

1st Digit – 8

2nd Digit – 3 – Single Pitch Selective Ribbon
4 – Single Pitch Fabric Ribbon
5 – Single Pitch Correcting "Selectric" Typewriter
7 – Dual Pitch Selective Ribbon
8 – Dual Pitch Fabric Ribbon
9 – Dual Pitch Correcting "Selectric" Typewriter

3rd Digit – 3 – 11" writing line
5 – 13" writing line

"SELECTRIC" III AND CORRECTING "SELECTRIC" III TYPEWRITERS – PRODUCT CODE 27

MACHINE TYPE	MODEL CODE
13.5" Single Pitch Fabric	6701
13.5" Single Pitch Non-Correcting	6702
15.5" Single Pitch Correcting	6703
13.5" Dual Pitch Correcting	6704
15.5" Dual Pitch Correcting	6705

96-CHARACTER "SELECTRIC" TYPEWRITER

1st Digit – 9

2nd Digit – 6 – Single Pitch Selective Ribbon
4 – Single Pitch Fabric Ribbon
5 – Single Pitch Correcting "Selectric" Typewriter
1 – Dual Pitch Selective Ribbon
2 – Dual Pitch Fabric Ribbon
9 – Dual Pitch Correcting "Selectric" Typewriter

3rd Digit – 3 – 11" writing line
5 – 13" writing line

International Business Machines Corporation
Office Products Division
Customer Engineering

IBM "Selectric" Typewriter Adjustment Parts Manual
S241-5939-2

S241-5939-2

Printed In USA (Revised) April, 1980